


**SF-2100/SF-2150**

**SF-2200/SF-2250**



**PARTS LIST—SF-2100/SF-2150/SF-2200/SF-2250**

Item No.	Code No.	Part No.	Description
1A.	—	—	Pedestal Faucet Assembly w/Outlet (Models SF-2100 and SF-2150)
1B.	—	—	Gooseneck Faucet Assembly w/Outlet (Models SF-2200 and SF-2250)
—	<b>0362004</b>	SFP-4	Mounting Hardware Kit, Pedestal Faucet (Models SF-2100/SF-2150); includes Items 2A, 2B, 2C, 2D and 2E
—	<b>0362005</b>	SFP-5	Mounting Hardware Kit, Gooseneck Faucet (Models SF-2200/2250); includes Items 2A, 2B and 2E
2A.	—	—	Gasket
2B.	—	—	Metal Retainer
2C.	—	—	Threaded Studs (Models SF-2100/2150)
2D.	—	—	Retainer Nuts (Models SF-2100/2150)
2E.	—	—	Screws and Anchors for Control Module (all models)
3.	<b>0362006</b>	SFP-6	110 VAC/6 VDC Plug-In Adapter (US) (Models SF-2100 and SF-2200)
4.	—	—	Batteries, 4 AA-size (all models)
5A.	<b>0362040</b>	SFP-40-A	Control Module with Adjustable Button (6 pin connector)
5B.	<b>0362008</b>	SFP-8	Control Module (Old Style 4 pin connector)*
6.	<b>0362010</b>	SFP-10	Flex Hose, Control Module to Spout (all models)
7.	—	—	Inlet adapter – 1/2" NPSM to 3/8" Compression Connection (not supplied with most international models)
8.	<b>0362011</b>	SFP-11	4" Trim Plate with Spacer (all models)
9.	<b>0362030</b>	SFP-30A	Faucet Extension Kit (Models SF-2100/2150)
10A.	<b>0362041</b>	SFP-41-A	Sensor Assembly (6 pin connector)
10B.	<b>0362034</b>	SFP-34	Sensor Assembly (Old Style 4 pin connector)*
11.	<b>3365461</b>	ETF-617-A	3/8" Bak-Chek® Tee Compression Fitting

\* IMPORTANT: Sloan added the range adjustment feature in August 2008 for faucets made prior to August 2008 use the following replacement parts: SFP-34 and SFP-8

**NOT SHOWN SEPARATELY**

—	<b>0362012</b>	SFP-12	Gooseneck Spout w/Outlet (Models SF-2200/2250)
—	<b>0362014</b>	SFP-14	Spray Head for Gooseneck Faucet (Models SF-2200/2250)
—	<b>0362013</b>	SFP-13	0.5 gpm/1.9 Lpm Spray head (Models: SF-2100/2150)
—	<b>0335012</b>	EAF-15	0.5 gpm/1.9 vandal resistant spray head (Models: SF-2100/2150)
—	<b>0362023</b>	SFP-23	2.2 gpm/8.3 Lpm Aerator (Models: SF-2100/2150)
—	<b>0362024</b>	SFP-24	2.2 gpm/8.3 Lpm vandal resistant aerator (Models: SF-2100/2150)
—	<b>0362020</b>	SFP-26	220 VAC/6 VDC Plug-In Adapter (ASIA)
—	<b>0362025</b>	SFP-25	220 VAC/6 VDC Plug-In Adapter (EURO)
—	<b>0362026</b>	SFP-20	220 VAC/6 VDC Plug-In Adapter (UK)
—	<b>3362022</b>	SFP-22-A	8" Trim Plate

**ACCESSORIES**

12.	<b>0362035</b>	SFP-35-A	100-240 VAC/6 VDC Gang Adapter Kit, includes 12A, 12B and 12C
12A.	<b>0362016</b>	SFP-36-A	100-240 VAC/6 VDC Plug-In Adapter
12B.	<b>0362018</b>	SFP-38	Cable Splitter, 51"/1300 mm (5 included in kit)
12C.	<b>0362017</b>	SFP-37	Cable Extension, 51"/1300 mm

**REPAIR PARTS**

13.	<b>0362015</b>	SFP-15	Strainer (located in water inlet of control module)
-----	----------------	--------	---

— in Item No. column = Not shown in illustration

— in Code No. and Part No. column = Not sold separately

**SF-2100/SF-2150****SF-2200/SF-2250**

## TROUBLESHOOTING GUIDE

1. Faucet delivers water in an uncontrolled manner.
  - A. Faucet is not working properly.  
Contact the Sloan Valve Company Installation Engineering Department at 1-888-SLOAN-14 (1-888-756-2614).
2. Faucet does not deliver any water when Sensor is activated.
 

INDICATOR: Solenoid valve produces an audible "CLICK."

  - A. Water supply stop(s) closed. Open water supply stop(s).
  - B. Water strainer in control module is clogged. Close supply stops and remove water inlet line at control module. Remove, clean and reinstall strainer and water inlet line. Replace strainer if required.

INDICATOR: Solenoid valve DOES NOT produce an audible "CLICK."

  - A. Batteries low (battery powered models). Replace batteries.
  - B. Power failure (transformer powered models). Check power supply.
3. Faucet delivers only a slow flow or dribble when Sensor is activated.
  - A. Water supply stop(s) are partially closed. Completely open water supply stop(s).
  - B. Water strainer in control module is clogged. Close supply stops and remove water inlet line at control module. Remove, clean and reinstall strainer and water inlet line. Replace strainer if required.
  - C. Aerator is clogged. Remove, clean, and reinstall aerator. Replace aerator if required.
  - D. Faucet is not working properly.  
Contact the Sloan Valve Company Installation Engineering Department at 1-888-SLOAN-14 (1-888-756-2614).
4. Faucet does not stop delivering water or continues to drip after user is no longer detected.
  - A. Faucet is not working properly.  
Contact the Sloan Valve Company Installation Engineering Department at 1-888-SLOAN-14 (1-888-756-2614).
5. The water temperature is too hot or too cold on a Faucet connected to hot and cold supply lines.
  - A. Supply Stops are not adjusted properly. Adjust Supply Stops.

## CARE AND CLEANING INSTRUCTIONS

DO NOT use abrasive or chemical cleaners (including chlorine bleach) to clean faucet that may dull the luster and attack the chrome or special decorative finishes. Use ONLY mild soap and water, then wipe dry with clean cloth or towel. While cleaning the bathroom tile, protect the faucet from any splattering of cleaner. Acids and cleaning fluids will discolor or remove chrome plating.

When assistance is required, please contact Sloan Valve Company Installation Engineering Department at: 1-888-SLOAN-14 (1-888-756-2614).