

# Air Delights

[www.airdelights.com](http://www.airdelights.com)

Air Delights, Inc.  
Customer\_Service@AirDelights.com  
<http://www.airdelights.com>  
Phone: 503-352-1201  
Fax: 503-643-8224

## MULTI-FUNCTION AEROSOL DISPENSER SYSTEM

### Wall Mounting

For permanent installation, position screws ( included) over a wall stud and secure to wall. Double-stick tape is already affixed to the dispenser for use on a CLEAN non-porous surface.

### Instructions

1. Open dispenser by pushing the top button ( Fig. A) and pull cover forward. Dispenser cover is hinged at bottom ( Fig. B). To clean dispenser cover, simply remove from hinges and wash in warm water with a mild detergent.
2. Insert two fresh D-Cell alkaline batteries ( Fig. C) into the designated slot at the top of the unit, making sure the positive (+) and negative (-) ends of the batteries are positioned properly.  
CHECK LCD MAKING SURE THE DISPENSER IS IN THE OFF MODE PRIOR TO INSERTING THE CAN.
3. Setting clock - Press MODEL ( Fig. D) button until CLOCK Appears in the bottom right corner, then press the hour and minute buttons until the current time appears.\*
4. Setting on/off time - The unit will operate 24 hrs. A day unless programmed differently. Press MODEL ( Fig. D) button until START appears, then press the HOUR ( Fig. E) and MIN. ( Fig. F) button until the desired start time is on the display.  
Repeat this procedure for the STOP function setting the desired stop time.\*
5. Setting spray interval - The unit is pre-set at a 15 minute spray interval, all other desired intervals must be programmed. Press Mode ( Fig. D) button until interval appears, then press the MIN. ( Fig. F) button until the desired spray. Interval appears (1-60 minutes).
6. Place a metered aerosol can into the dispenser, making sure the tip is facing forward and the shoulder of the can ( Fig. J) is resting securely in the metal retaining bracket ( Fig. H).  
IT IS IMPORTANT THAT THE UNITS IS IN THE OFF MODE, THEN RESET BY PRESSING THE ON/OFF BUTTON ( Fig. G) EACH TIME THE CAN OR BATTERIES ARE REPLACED.
7. To activate the unit press the ON/OFF button ( Fig. G), the LED indicator will flash green/red 3 times and the actuating arm will activate 1 time as system check.  
TO AVOID BEING SPRAYED WHEN THE UNIT ACTIVATES, DO NOT STAND IN FRONT OF THE DISPENSER.
8. Close the cover, making sure the Opening Button ( Fig. A) is securely in the opening.  
DURING NORMAL OPERATION  
Green LED blinks approximately every 5 seconds.  
Red LED blinks to indicate it is time to replace the aerosol can.  
No blinking lights indicates the need to replace batteries.  
IMPORTANT: SPRAY counting mechanism will let you know the number of times the unit has activated ( counts to 3,000 in according order. This function MUST be reset with each can or battery replacement. This is done by pressing the ON/OFF button ( Fig. G) when the SPRAY function is in the display.

**CAUTION: DO NOT EXPOSE EYE TO FRONT OF SPRAY TIP WHEN CHANGING AEROSOL CAN. DO NOT OPERATE THE UNIT WITHOUT AN AEROSOL CAN IN PLACE.**

\* KEEP IN MIND THIS IS A 24 HR. (Military Time) CLOCK, I.e.7:00 PM WILL DISPLAY 19:00

