

5151, 5153

## **INSTRUCTIONS FOR INSTALLING** 5151, 5153 THROW LATCH OUTSWING **APPLICATION** Pilaster Post 5180 Keeper (mounted on door) Door 0 - 5151 **Throw Latch** 5170 Strike (mounted inside of post)

## **NOTE: 5400 DOOR PULL MOUNTED ON OUTSIDE OF DOOR** (HOLES ARE TO LINE UP WITH HOLES ON MOUNTING PLATE OF THROW LATCH)