Repair Parts and Maintenance Guide


Optima[®] Dual-Flush and Single-Flush Side Mount Unit

Battery-powered, sensor-activated, retrofit unit for exposed, dual-flush and single-flush closet and single-flush urinal.

PARTS LIST

Code No.	Part No.	Description
3325506	EBV-505-A	Dual-Flush Sleeve Assembly
3325507	EBV-570-A	Single-Flush Sleeve Assembly
0372049	WES-46	DFSM Wall Plate
3325509	EBV-576	GEM Adapter Kit for SFSM
5325376		GEM Yellow Gasket (Pack of 5)
		_
		2.5 mm Hex Wrench for Battery Compartment
0325380	EBV-545	Collar Wrench
		4 C-Cell Batteries (factory installed
3325204	EBV-1014-A	Battery Tray Assembly
	3325506 3325507 0372049 3325509 5325376 0325380 	3325506 EBV-505-A 3325507 EBV-570-A 0372049 WES-46 3325509 EBV-576 5325376 0325380 EBV-545

* Refer to Royal Maintenance Guide for flushometer components.





ally. The Du


SLOAN

4

5







The information contained in this document is subject to change without notice.

and will

WES-46 - REV1 (03/13



Optima Dual-Flush and Single-Flush Side Mount Unit

BATTERY REPLACEMENT

Using the supplied battery compartment hex wrench, remove battery compartment from Side Mount unit.

Remove batteries from compartment tray



TOP VIEW

Install 4 new C-cell batteries into compartment tray (note the position of batteries in tray), and reinstall compartment tray into the Side Mount unit.

The Side Mount unit comes preset from the factory. If special circumstances require adjustment of the activation distance, please contact Sloan.



The Side Mount unit calibrates upon power up, GREEN and RED LEDs flash once. The unit will actuate a flush followed by 5 flashes of GREEN LED. The unit will then perform calibration, a 20 second sequence, where the GREENide mount unit or flushometer that may dull the luster and attack the LED flashes guickly. Finally the unit will start normal operation.

Manual flush button on Side Mount unit allows manual activation, when desired.

MODE CHANGE (SINGLE-FLUSH UNITS ONLY)

Units are preset at factory in water closet mode.

To change unit from water closet to urinal mode, complete the follow log sensor window that may distort or ruin the sensor.

Press and hold the True Mechanical Override (TMO) button for 20-30 seconds.

The unit will exhibit an LED flash pattern as follows:

- For approximately the first 10 seconds there will be no LED flashing
- For approximately seconds 10-20, both the RED and GREEN LEDs will produce short simultaneous flashes
- For approximately seconds 20-30, the GREEN LED will flash

Release the TMO button during the 20-30 seconds when both the RED and GREEN LEDs produce SHORT simultaneous flashes and remove nonpermanent items from view of the sensor. The Side Mount unit will now be in urinal mode* and begin calibration.

To change back to closet mode, press and hold the TMO button for 30-40 seconds. Release when RED and GREEN LEDs produce short simultaneous flashes. The Side Mount unit will now be in close mode and begin calibration.

* Urinal mode provides a shorter sensor range and 1-2 second flush delay.

TROUBLESHOOTING GUIDE

- 1. RED LED continuously flashes when target is present. The battery is low. Refer to battery replacement instructions.
- 2. RED LED flashes 4 times after a target has been present for 8 seconds. RED LED flashes once when a target is NOT present.
- The battery is low. Refer to battery replacement instructions.
- 3. RED LED flashes continuously after calibration.
 - The unit has failed to calibrate. The optics window is obscured. Remove power, clean window and remove any objects (barrels, toolboxes, etc.) within close proximity of unit. Repeat power-up sequence (See BATTERY REPLACEMENT for power-up sequence). If unit fails, consult Sloan Technical Support.

CARE AND CLEANING OF CHROME AND SPECIAL FINISHES

DO NOT USE brasive or chemical cleaners (including chlorine bleach finishe. Use ONLYmild soap and water, then wipe dry with clean cloth towel.

While cleaning the bathroom tile, protect the side mount unit from a splattering of cleaner. Acids and cleaning fluids can discolor or remove chrome plating.

DO NOT USE brasive or chemical cleaners (including chlorine bleach

When assistance is required, please contact

Air Delights Technical Support 1-800-440-5556 or visit AirDelights.com

The information contained in this document is subject to change without notice.